

THE CONTROLS




FIGURE 1, The controls.

(Specification details vary according to model. The lower illustration refers to the Moto-cross model only).

- | | |
|---|---|
| <p>A Warning lights :
Green-main beam
Red-oil pressure (250 cm³ only)
Amber--direction indicators.
B Headlight switch.
C Direction indicator lights
(also at rear).
D Steering lock.
E Front brake cable adjuster.
F Throttle cable adjuster.
G Front brake lever.
H Ignition cut-out.
J Direction indicator switch.
K Throttle twist grip control (open
in direction of arrow).</p> | <p>L Oil filler.
M Gearchange pedal.
N Starter pedal.
O Gasoline (petrol) taps.
P Brake pedal.
Q Gasoline (petrol) filler.
R Master switch key.
S Exhaust valve lifter lever (500 cm³
models, except Moto-cross).
T Horn switch.
U Headlight dip switch.
V Clutch lever,
W Headlight flasher switch.
X Clutch cable adjuster.
Y Speedometer.</p> |
|---|---|